PJ Currier Lumber

CUSTOM CURVED INTERIOR CASING

Full Circle



1/2 Round



1/4 Round



To measure for casing of a true radius window:

A true radius means that the arc is part of a circle. Measure inside diameter or radius of circle (specify). Add ½" to diameter for casing reveal (¼" each side).

Eyebrow

Height is less than half the width



Eyebrow w/ springline



Eyebrow/circle segment



To measure for casing of an eyebrow:

To find "X"—measure inside to inside of jamb at the widest point.
To find "Y"—measure from the center of "X" to top inside of jamb. Make sure you are 90° to the chord "X".
We will calculate the diameter of the circle from these measurements. We will allow for ¼" reveal on casing unless specified otherwise.

Full Elipse

Not a true radius



1/2 Elipse

Not a true radius



To measure for casing for an eliptical window:

Eliptical casing requires a hard template. Templates should be ¼" MDF or masonite. Attach sheet to the wall, covering the window. Cut out with router and flush trim bit. Follow inside of curve with ball bearing bit. Paper templates are *not acceptable*, as there is no accurate way to transfer the line to solid material. Consider cutting template before window is installed, especially if it is to be installed up high.